

**CPE2026-004 – Vulnerability Remediation for My Image Garden for macOS and CUPS Printer Driver for macOS – 28 May 2026**

**Affected Products/Models**

Products	Software for macOS	Affected Software Version	Fix Software Version	CVE-2026-6891	CVE-2026-6892
CanoScan 9000F Mark II	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
CanoScan LiDE 120	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
CanoScan LiDE 220	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA E204	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA E304	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA E3140	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA E404	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA E414	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA E464	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA E474	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA E484	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA E514	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA G2400	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA G2500	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA G2501	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA G3400	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA G3500	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA G3501	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA G4400	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA G4410	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA G4411	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA G4500	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA G4510	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA G4511	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA iP100	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA iP110	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA iP1900	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA iP2600	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓

Products	Software for macOS	Affected Software Version	Fix Software Version	CVE-2026-6891	CVE-2026-6892
PIXMA iP2700	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA iP2702	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA iP2840	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA iP2845	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA iP2850	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA iP2855	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA iP3500	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA iP3600	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA iP4500	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA iP4600	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA iP4700	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA iP4840	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA iP4850	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA iP4940	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA iP4950	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA iP7240	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA iP7250	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA iP8740	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA iP8750	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA iX6540	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA iX6550	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA iX6840	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA iX6840	CUPS Driver	16.91.0.0 or earlier	16.91.1.0 or higher	✓	✓
PIXMA iX6850	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA iX6850	CUPS Driver	16.91.0.0 or earlier	16.91.1.0 or higher	✓	✓
PIXMA iX7000	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG2140	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG2150	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG2155	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG2240	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG2245	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG2250	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG2255	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG2440	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG2450	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG2455	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG2540	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓

Products	Software for macOS	Affected Software Version	Fix Software Version	CVE-2026-6891	CVE-2026-6892
PIXMA MG2540	CUPS Driver	16.91.0.0 or earlier	16.91.1.0 or higher	✓	✓
PIXMA MG2540S	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG2540S	CUPS Driver	16.91.0.0 or earlier	16.91.1.0 or higher	✓	✓
PIXMA MG2541S	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG2541S	CUPS Driver	16.91.0.0 or earlier	16.91.1.0 or higher	✓	✓
PIXMA MG2545	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG2545	CUPS Driver	16.91.0.0 or earlier	16.91.1.0 or higher	✓	✓
PIXMA MG2545S	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG2545S	CUPS Driver	16.91.0.0 or earlier	16.91.1.0 or higher	✓	✓
PIXMA MG2550	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG2550	CUPS Driver	16.91.0.0 or earlier	16.91.1.0 or higher	✓	✓
PIXMA MG2550S	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG2550S	CUPS Driver	16.91.0.0 or earlier	16.91.1.0 or higher	✓	✓
PIXMA MG2551S	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG2551S	CUPS Driver	16.91.0.0 or earlier	16.91.1.0 or higher	✓	✓
PIXMA MG2555	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG2555	CUPS Driver	16.91.0.0 or earlier	16.91.1.0 or higher	✓	✓
PIXMA MG2555S	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG2555S	CUPS Driver	16.91.0.0 or earlier	16.91.1.0 or higher	✓	✓
PIXMA MG2556S	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG2556S	CUPS Driver	16.91.0.0 or earlier	16.91.1.0 or higher	✓	✓
PIXMA MG2940	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG2945	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG2950	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓

Products	Software for macOS	Affected Software Version	Fix Software Version	CVE-2026-6891	CVE-2026-6892
PIXMA MG2950S	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG2955	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG3040	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG3050	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG3051	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG3052	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG3053	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG3140	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG3150	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG3155	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG3240	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG3250	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG3255	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG3540	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG3550	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG3640	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG3640S	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG3650	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG3650S	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG4140	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG4150	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG4240	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG4250	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG5140	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG5150	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG5240	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG5250	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG5340	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG5350	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG5350S	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG5440	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG5450	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG5450S	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG5522	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG5540	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓

Products	Software for macOS	Affected Software Version	Fix Software Version	CVE-2026-6891	CVE-2026-6892
PIXMA MG5550	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG5640	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG5650	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG5655	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG5740	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG5750	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG5751	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG5752	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG5753	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG6140	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG6150	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG6240	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG6250	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG6340	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG6350	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG6440	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG6450	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG6640	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG6650	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG6840	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG6850	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG6851	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG6852	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG6853	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG7140	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG7150	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG7540	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG7550	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG7740	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG7750	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG7751	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG7752	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG7753	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG8140	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG8150	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG8240	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MG8250	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA mini320	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓

Products	Software for macOS	Affected Software Version	Fix Software Version	CVE-2026-6891	CVE-2026-6892
PIXMA MP140	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MP190	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MP210	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MP220	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MP230	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MP235	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MP240	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MP250	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MP252	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MP260	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MP270	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MP272	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MP280	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MP282	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MP470	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MP480	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MP490	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MP492	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MP495	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MP499	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MP520	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MP540	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MP550	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MP560	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MP610	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MP620	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MP620B	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MP630	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MP640	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MP640R	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MP970	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MP980	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MP990	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX300	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX310	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX320	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX330	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX340	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓

Products	Software for macOS	Affected Software Version	Fix Software Version	CVE-2026-6891	CVE-2026-6892
PIXMA MX350	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX360	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX374	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX375	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX394	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX395	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX410	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX420	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX434	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX435	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX454	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX455	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX474	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX475	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX494	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX495	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX514	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX515	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX524	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX525	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX534	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX535	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX700	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX714	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX715	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX725	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX7600	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX850	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX860	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX870	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX884	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX885	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX894	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX895	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX924	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA MX925	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA PRO-1	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA PRO-10	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓

Products	Software for macOS	Affected Software Version	Fix Software Version	CVE-2026-6891	CVE-2026-6892
PIXMA PRO-100	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA PRO-1000	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA PRO-100S	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA PRO-10S	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA Pro9000 Mark II	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA Pro9500 Mark II	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TR7540	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TR7550	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TR8540	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TR8550	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS204	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS205	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS304	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS305	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS3140	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS3150	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS3151	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS5040	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS5050	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS5051	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS5053	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS5055	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS5140	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS5150	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS5151	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS6040	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS6050	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS6051	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS6052	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS6140	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS6150	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS6151	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS8040	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS8050	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓

<b>Products</b>	<b>Software for macOS</b>	<b>Affected Software Version</b>	<b>Fix Software Version</b>	<b>CVE-2026-6891</b>	<b>CVE-2026-6892</b>
PIXMA TS8051	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS8052	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS8053	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS8140	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS8150	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS8151	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS8152	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS9040	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS9050	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS9055	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS9140	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS9150	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓
PIXMA TS9155	My Image Garden	3.6.8 or earlier	3.6.8a or higher	✓	✓