

# ÜHILDUVAD PRINTERID

## imagePROGRAF-i seeria

|                               |                               |                              |                             |
|-------------------------------|-------------------------------|------------------------------|-----------------------------|
| imagePROGRAF TC-20            | imagePROGRAF TX-3100          | imagePROGRAF iPF685          | imagePROGRAF iPF8300        |
| imagePROGRAF TC-20M           | imagePROGRAF TX-3100 MFP Z36  | imagePROGRAF iPF700          | imagePROGRAF iPF8300S       |
| imagePROGRAF GP-200           | imagePROGRAF TX-4000          | imagePROGRAF iPF710          | imagePROGRAF iPF840         |
| imagePROGRAF GP-2000          | imagePROGRAF TX-4000 MFP T36  | imagePROGRAF iPF720          | imagePROGRAF iPF840 MFP M40 |
| imagePROGRAF GP-300           | imagePROGRAF TX-4100          | imagePROGRAF iPF750          | imagePROGRAF iPF8400        |
| imagePROGRAF GP-4000          | imagePROGRAF TX-4100 MFP Z36  | imagePROGRAF iPF750 M40 MFP  | imagePROGRAF iPF8400S       |
| imagePROGRAF PRO-2000         | imagePROGRAF TZ-30000         | imagePROGRAF iPF755          | imagePROGRAF iPF8400SE      |
| imagePROGRAF PRO-2100         | imagePROGRAF TZ-30000 MFP Z36 | imagePROGRAF iPF755 M40 MFP  | imagePROGRAF iPF850         |
| imagePROGRAF PRO-4000         | imagePROGRAF iPF500           | imagePROGRAF iPF760          | imagePROGRAF iPF850 MFP M40 |
| imagePROGRAF PRO-4000S        | imagePROGRAF iPF5000          | imagePROGRAF iPF760 M40 MFP  | imagePROGRAF iPF9000        |
| imagePROGRAF PRO-4100         | imagePROGRAF iPF510           | imagePROGRAF iPF765          | imagePROGRAF iPF9000S       |
| imagePROGRAF PRO-4100S        | imagePROGRAF iPF5100          | imagePROGRAF iPF765 M40 MFP  | imagePROGRAF iPF9100        |
| imagePROGRAF PRO-6000         | imagePROGRAF iPF600           | imagePROGRAF iPF770          | imagePROGRAF iPF9400        |
| imagePROGRAF PRO-6000S        | imagePROGRAF iPF6000S         | imagePROGRAF iPF770 MFP L36  | imagePROGRAF iPF9400S       |
| imagePROGRAF PRO-6100         | imagePROGRAF iPF605           | imagePROGRAF iPF770 MFP L36e | imagePROGRAF PRO-1000       |
| imagePROGRAF PRO-6100S        | imagePROGRAF iPF610           | imagePROGRAF iPF770 MFP M40  | imagePROGRAF PRO-300        |
| imagePROGRAF TA-20            | imagePROGRAF iPF6100          | imagePROGRAF iPF780          |                             |
| imagePROGRAF TA-30            | imagePROGRAF iPF6200          | imagePROGRAF iPF780 MFP M40  |                             |
| imagePROGRAF TM-200           | imagePROGRAF iPF6300          | imagePROGRAF iPF785          |                             |
| imagePROGRAF TM-200 MFP L24ei | imagePROGRAF iPF6300S         | imagePROGRAF iPF785 MFP M40  |                             |
| imagePROGRAF TM-205           | imagePROGRAF iPF6350          | imagePROGRAF iPF8000         |                             |
| imagePROGRAF TM-300           | imagePROGRAF iPF6400          | imagePROGRAF iPF8000S        |                             |
| imagePROGRAF TM-300 MFP L36ei | imagePROGRAF iPF6400S         | imagePROGRAF iPF810          |                             |
| imagePROGRAF TM-300 MFP Z36   | imagePROGRAF iPF6400SE        | imagePROGRAF iPF8100         |                             |
| imagePROGRAF TM-305           | imagePROGRAF iPF6450          | imagePROGRAF iPF815          |                             |
| imagePROGRAF TM-305 MFP T36   | imagePROGRAF iPF650           | imagePROGRAF iPF815 M40 MFP  |                             |
| imagePROGRAF TM-305 MFP Z36   | imagePROGRAF iPF655           | imagePROGRAF iPF820          |                             |
| imagePROGRAF TX-2000          | imagePROGRAF iPF670           | imagePROGRAF iPF825          |                             |
| imagePROGRAF TX-2100          | imagePROGRAF iPF670 MFP L24   | imagePROGRAF iPF825 M40 MFP  |                             |
| imagePROGRAF TX-3000          | imagePROGRAF iPF670 MFP L24e  | imagePROGRAF iPF830          |                             |
| imagePROGRAF TX-3000 MFP T36  | imagePROGRAF iPF680           | imagePROGRAF iPF830 MFP M40  |                             |

# ÜHILDUVAD PRINTERID

## PIXMA seeria

|             |             |              |               |
|-------------|-------------|--------------|---------------|
| PIXMA E204  | PIXMA G2570 | PIXMA G6045  | PIXMA MG7751  |
| PIXMA E304  | PIXMA G3400 | PIXMA G6050  | PIXMA MG7752  |
| PIXMA E3140 | PIXMA G3410 | PIXMA G6055  | PIXMA MG7753  |
| PIXMA E3340 | PIXMA G3415 | PIXMA G640   | PIXMA PRO-200 |
| PIXMA E3440 | PIXMA G3420 | PIXMA G650   | PIXMA TR150   |
| PIXMA E414  | PIXMA G3430 | PIXMA G7040  | PIXMA TR4540  |
| PIXMA E4240 | PIXMA G3460 | PIXMA G7045  | PIXMA TR4550  |
| PIXMA E474  | PIXMA G3470 | PIXMA G7050  | PIXMA TR4551  |
| PIXMA G1400 | PIXMA G3500 | PIXMA G7055  | PIXMA TR4640  |
| PIXMA G1410 | PIXMA G3501 | PIXMA GM2050 | PIXMA TR4650  |
| PIXMA G1411 | PIXMA G3510 | PIXMA GM4040 | PIXMA TR4750i |
| PIXMA G1420 | PIXMA G3520 | PIXMA GM4050 | PIXMA TR4751i |
| PIXMA G1430 | PIXMA G3560 | PIXMA MG3040 | PIXMA TR7540  |
| PIXMA G1500 | PIXMA G3570 | PIXMA MG3050 | PIXMA TR7550  |
| PIXMA G1501 | PIXMA G3571 | PIXMA MG3051 | PIXMA TR8540  |
| PIXMA G1510 | PIXMA G3572 | PIXMA MG3052 | PIXMA TR8550  |
| PIXMA G1520 | PIXMA G4400 | PIXMA MG3053 | PIXMA TS204   |
| PIXMA G1530 | PIXMA G4410 | PIXMA MG3640 | PIXMA TS205   |
| PIXMA G2400 | PIXMA G4470 | PIXMA MG3650 | PIXMA TS304   |
| PIXMA G2410 | PIXMA G4411 | PIXMA MG5740 | PIXMA TS305   |
| PIXMA G2411 | PIXMA G4500 | PIXMA MG5750 | PIXMA TS3140  |
| PIXMA G2415 | PIXMA G4510 | PIXMA MG5751 | PIXMA TS3150  |
| PIXMA G2420 | PIXMA G4570 | PIXMA MG5752 | PIXMA TS3151  |
| PIXMA G2430 | PIXMA G4511 | PIXMA MG5753 | PIXMA TS3340  |
| PIXMA G2460 | PIXMA G5040 | PIXMA MG6840 | PIXMA TS3350  |
| PIXMA G2470 | PIXMA G5045 | PIXMA MG6850 | PIXMA TS3351  |
| PIXMA G2500 | PIXMA G5050 | PIXMA MG6851 | PIXMA TS3352  |
| PIXMA G2501 | PIXMA G5055 | PIXMA MG6852 | PIXMA TS3355  |
| PIXMA G2510 | PIXMA G540  | PIXMA MG6853 | PIXMA TS3440  |
| PIXMA G2520 | PIXMA G550  | PIXMA MG7740 | PIXMA TS3450  |
| PIXMA G2560 | PIXMA G6040 | PIXMA MG7750 | PIXMA TS3451  |

# ÜHILDUVAD PRINTERID

## PIXMA seeria

|               |               |               |               |
|---------------|---------------|---------------|---------------|
| PIXMA TS3452  | PIXMA TS5353  | PIXMA TS704a  | PIXMA TS8251  |
| PIXMA TS3550i | PIXMA TS5353a | PIXMA TS705   | PIXMA TS8252  |
| PIXMA TS3551i | PIXMA TS5355  | PIXMA TS705a  | PIXMA TS8340  |
| PIXMA TS5040  | PIXMA TS5355a | PIXMA TS7440  | PIXMA TS8340a |
| PIXMA TS5050  | PIXMA TS6040  | PIXMA TS7440a | PIXMA TS8350  |
| PIXMA TS5051  | PIXMA TS6050  | PIXMA TS7450  | PIXMA TS8350a |
| PIXMA TS5053  | PIXMA TS6051  | PIXMA TS7450a | PIXMA TS8351  |
| PIXMA TS5055  | PIXMA TS6052  | PIXMA TS7450i | PIXMA TS8351a |
| PIXMA TS5140  | PIXMA TS6140  | PIXMA TS7451  | PIXMA TS8352  |
| PIXMA TS5150  | PIXMA TS6150  | PIXMA TS7451a | PIXMA TS8352a |
| PIXMA TS5151  | PIXMA TS6151  | PIXMA TS7451i | PIXMA TS9040  |
| PIXMA TS5340  | PIXMA TS6240  | PIXMA TS8040  | PIXMA TS9050  |
| PIXMA TS5340a | PIXMA TS6250  | PIXMA TS8050  | PIXMA TS9055  |
| PIXMA TS5350  | PIXMA TS6251  | PIXMA TS8051  | PIXMA TS9140  |
| PIXMA TS5350a | PIXMA TS6340  | PIXMA TS8052  | PIXMA TS9150  |
| PIXMA TS5350i | PIXMA TS6340a | PIXMA TS8053  | PIXMA TS9155  |
| PIXMA TS5351i | PIXMA TS6350  | PIXMA TS8140  | PIXMA TS9540  |
| PIXMA TS5351  | PIXMA TS6350a | PIXMA TS8150  | PIXMA TS9541C |
| PIXMA TS5351a | PIXMA TS6351  | PIXMA TS8151  | PIXMA TS9550  |
| PIXMA TS5352  | PIXMA TS6351a | PIXMA TS8152  | PIXMA TS9551C |
| PIXMA TS5352a | PIXMA TS704   | PIXMA TS8240  |               |

## MAXIFY seeria

|               |               |               |               |
|---------------|---------------|---------------|---------------|
| MAXIFY GX3040 | MAXIFY GX7040 | MAXIFY MB2750 | MAXIFY MB5450 |
| MAXIFY GX3050 | MAXIFY GX7050 | MAXIFY MB2755 | MAXIFY MB5455 |
| MAXIFY GX4040 | MAXIFY MB2140 | MAXIFY MB5140 | MAXIFY iB4140 |
| MAXIFY GX4050 | MAXIFY MB2150 | MAXIFY MB5150 | MAXIFY iB4150 |
| MAXIFY GX6040 | MAXIFY MB2155 | MAXIFY MB5155 | MAXIFY GX5040 |
| MAXIFY GX6050 | MAXIFY MB2740 | MAXIFY MB5440 | MAXIFY GX5050 |
| MAXIFY GX6050 | MAXIFY MB2740 | MAXIFY MB5440 | MAXIFY GX5050 |

**Canon**

# ÜHILDUVAD PRINTERID

## imagePRESS-i seeria

|                      |                     |                    |                   |
|----------------------|---------------------|--------------------|-------------------|
| imagePRESS C10000VP* | imagePRESS C265     | imagePRESS C810*   | imagePRESS V800*  |
| imagePRESS C10010VP* | imagePRESS C270     | imagePRESS C9010V* | imagePRESS V900*  |
| imagePRESS C165      | imagePRESS C710*    | imagePRESS C910*   | imagePRESS V1000* |
| imagePRESS C170      | imagePRESS C8000VP* | imagePRESS V700*   | imagePRESS V1350* |

## imageRUNNER ADVANCE'i seeria

|                                   |                               |                                |                               |
|-----------------------------------|-------------------------------|--------------------------------|-------------------------------|
| imageRUNNER ADVANCE C256i         | imageRUNNER ADVANCE C3525i    | imageRUNNER ADVANCE DX C259i   | imageRUNNER ADVANCE DX C5840i |
| imageRUNNER ADVANCE C356i         | imageRUNNER ADVANCE C3530i    | imageRUNNER ADVANCE DX C359i   | imageRUNNER ADVANCE DX C5850i |
| imageRUNNER ADVANCE C356P         | imageRUNNER ADVANCE DX C3720i | imageRUNNER ADVANCE DX C359P   | imageRUNNER ADVANCE DX C5860i |
| imageRUNNER ADVANCE DX C257i      | imageRUNNER ADVANCE DX C3725i | imageRUNNER ADVANCE C5535i     | imageRUNNER ADVANCE DX C5870i |
| imageRUNNER ADVANCE DX C357i      | imageRUNNER ADVANCE DX C3730i | imageRUNNER ADVANCE C5540i     | imageRUNNER ADVANCE C7565i    |
| imageRUNNER ADVANCE DX C357P      | imageRUNNER ADVANCE DX C3822i | imageRUNNER ADVANCE C5550i     | imageRUNNER ADVANCE C7570i    |
| imageRUNNER ADVANCE C475i         | imageRUNNER ADVANCE DX C3826i | imageRUNNER ADVANCE C5560i     | imageRUNNER ADVANCE C7580i    |
| imageRUNNER ADVANCE C475iZ        | imageRUNNER ADVANCE DX C3830i | imageRUNNER ADVANCE C5560i ES  | imageRUNNER ADVANCE DX C7765i |
| imageRUNNER ADVANCE DX C477i MFP  | imageRUNNER ADVANCE DX C3835i | imageRUNNER ADVANCE C5560i ES+ | imageRUNNER ADVANCE DX C7770i |
| imageRUNNER ADVANCE DX C477iZ MFP | imageRUNNER ADVANCE DX C3922i | imageRUNNER ADVANCE DX C5735i  | imageRUNNER ADVANCE DX C7780i |
| imageRUNNER ADVANCE DX C478i      | imageRUNNER ADVANCE DX C3926i | imageRUNNER ADVANCE DX C5740i  |                               |
| imageRUNNER ADVANCE DX C478iZ     | imageRUNNER ADVANCE DX C3930i | imageRUNNER ADVANCE DX C5750i  |                               |
| imageRUNNER ADVANCE C3520i        | imageRUNNER ADVANCE DX C3935i | imageRUNNER ADVANCE DX C5760i  |                               |

## imageRUNNER-i seeria

|                     |                     |                    |                    |
|---------------------|---------------------|--------------------|--------------------|
| imageRUNNER C1538iF | imageRUNNER C1533iF | imageRUNNER C3226i | imageRUNNER C3326i |
|---------------------|---------------------|--------------------|--------------------|

Vastutuse välistamine

\* PRISMAsync ei ole toetatud

**Canon**

# ÜHILDUVAD PRINTERID

## i-SENSYS-i/i-SENSYS X-i seeria

i-SENSYS LBP722Cdw

i-SENSYS LBP670 seeria

i-SENSYS MF832Cdw

i-SENSYS X C1533P

i-SENSYS LBP852Cx

i-SENSYS MF740 seeria

i-SENSYS X C1127i seeria

i-SENSYS X C1538P

i-SENSYS LBP620 seeria

i-SENSYS MF750 seeria

i-SENSYS X C1127P

i-SENSYS X C1946P

i-SENSYS LBP630 seeria

i-SENSYS MF640 seeria

i-SENSYS X C1333i seeria

i-SENSYS LBP660 seeria

i-SENSYS MF650 seeria

i-SENSYS X C1333P