

מדפסות תואמות

סדרה imagePROGRAF

imagePROGRAF iPF750/MFP	imagePROGRAF GP-6600S	imagePROGRAF TC-20
imagePROGRAF iPF755/MFP	imagePROGRAF PRO-300	imagePROGRAF TC-20M
imagePROGRAF iPF760/MFP	imagePROGRAF PRO-310	imagePROGRAF TC-21
imagePROGRAF iPF765/MFP	imagePROGRAF PRO-1000	imagePROGRAF TC-21M
imagePROGRAF iPF770/MFP	imagePROGRAF PRO-1100	imagePROGRAF TA-20
imagePROGRAF iPF780/MFP	imagePROGRAF PRO-2000	imagePROGRAF TA-30
imagePROGRAF iPF785/MFP	imagePROGRAF PRO-2100	imagePROGRAF TM-200/MFP
imagePROGRAF iPF8000/8000S	imagePROGRAF PRO-2600	imagePROGRAF TM-205
imagePROGRAF iPF8100	imagePROGRAF PRO-4000	imagePROGRAF TM-300/MFP
imagePROGRAF iPF810	imagePROGRAF PRO-4000S	imagePROGRAF TM-305/MFP
imagePROGRAF iPF815/MFP	imagePROGRAF PRO-4100	imagePROGRAF TM-240/MFP
imagePROGRAF iPF820	imagePROGRAF PRO-4100S	imagePROGRAF TM-340/MFP
imagePROGRAF iPF825/MFP	imagePROGRAF PRO-4600	imagePROGRAF TM-255/MFP
imagePROGRAF iPF830/MFP	imagePROGRAF PRO-6000	imagePROGRAF TM-350/MFP
imagePROGRAF iPF8300/8300S	imagePROGRAF PRO-6000S	imagePROGRAF TM-355/MFP
imagePROGRAF iPF840/MFP	imagePROGRAF PRO-6100	imagePROGRAF TX-2000
imagePROGRAF iPF8400	imagePROGRAF PRO-6100S	imagePROGRAF TX-2100
imagePROGRAF iPF8400S/8400SE	imagePROGRAF PRO-6600	imagePROGRAF TX-3000/MFP
imagePROGRAF iPF850/MFP	imagePROGRAF iPF5000/510	imagePROGRAF TX-3100/MFP
imagePROGRAF iPF9000/9000S	imagePROGRAF iPF5000/5100	imagePROGRAF TX-3200/MFP
imagePROGRAF iPF9100	imagePROGRAF iPF600/605/610	imagePROGRAF TX-4000/MFP
imagePROGRAF iPF9400/9400S	imagePROGRAF iPF6000S	imagePROGRAF TX-4100/MFP
	imagePROGRAF iPF6100/6200	imagePROGRAF TX-4200/MFP
	imagePROGRAF iPF6300/6300S	imagePROGRAF TZ-30000/MFP
	imagePROGRAF iPF6350/6450	imagePROGRAF TZ-32000/MFP
	imagePROGRAF iPF6400	imagePROGRAF GP-200
	imagePROGRAF iPF6400S/6400SE	imagePROGRAF GP-300
	imagePROGRAF iPF650/655	imagePROGRAF GP-2000
	imagePROGRAF iPF670/MFP	imagePROGRAF GP-4000
	imagePROGRAF iPF680/685	imagePROGRAF GP-2600S
	imagePROGRAF iPF700/710/720	imagePROGRAF GP-4600S

מדפסות תואמות

PIXMA סדרה

PIXMA MG7751	PIXMA G6045	PIXMA G3400	PIXMA E204
PIXMA MG7752	PIXMA G6050	PIXMA G3410	PIXMA E304
PIXMA MG7753	PIXMA G6055	PIXMA G3415	PIXMA E3140
PIXMA PRO-200	PIXMA G640	PIXMA G3420	PIXMA E3340
PIXMA PRO-200S	PIXMA G650	PIXMA G3430	PIXMA E3440
PIXMA TR150	PIXMA G7040	PIXMA G3460	PIXMA E414
PIXMA TR150 עם סוללה	PIXMA G7045	PIXMA G3470	PIXMA E4240
PIXMA TR4540	PIXMA G7050	PIXMA G3480	PIXMA E474
PIXMA TR4550	PIXMA G7055	PIXMA G3500	PIXMA G1400
PIXMA TR4551	PIXMA GM2040	PIXMA G3501	PIXMA G1410
PIXMA TR4640	PIXMA GM2050	PIXMA G3510	PIXMA G1411
PIXMA TR4650	PIXMA GM4040	PIXMA G3520	PIXMA G1420
PIXMA TR4750i	PIXMA GM4050	PIXMA G3560	PIXMA G1430
PIXMA TR4751i	PIXMA MG3040	PIXMA G3570	PIXMA G1500
PIXMA TR7540	PIXMA MG3050	PIXMA G3571	PIXMA G1501
PIXMA TR7550	PIXMA MG3051	PIXMA G3572	PIXMA G1510
PIXMA TR7640	PIXMA MG3052	PIXMA G3590	PIXMA G1520
PIXMA TR7650	PIXMA MG3053	PIXMA G4400	PIXMA G1530
PIXMA TR8540	PIXMA MG3640	PIXMA G4410	PIXMA G2400
PIXMA TR8550	PIXMA MG3650	PIXMA G4411	PIXMA G2410
PIXMA TS204	PIXMA MG5740	PIXMA G4470	PIXMA G2411
PIXMA TS205	PIXMA MG5750	PIXMA G4500	PIXMA G2415
PIXMA TS304	PIXMA MG5751	PIXMA G4510	PIXMA G2420
PIXMA TS305	PIXMA MG5752	PIXMA G4570	PIXMA G2430
PIXMA TS3140	PIXMA MG5753	PIXMA G4511	PIXMA G2460
PIXMA TS3150	PIXMA MG6840	PIXMA G5040	PIXMA G2470
PIXMA TS3151	PIXMA MG6850	PIXMA G5045	PIXMA G2500
PIXMA TS3340	PIXMA MG6851	PIXMA G5050	PIXMA G2501
PIXMA TS3350	PIXMA MG6852	PIXMA G5055	PIXMA G2510
PIXMA TS3351	PIXMA MG6853	PIXMA G540	PIXMA G2520
PIXMA TS3352	PIXMA MG7740	PIXMA G550	PIXMA G2560
	PIXMA MG7750	PIXMA G6040	PIXMA G2570



מדפסות תואמות

PIXMA סדרה

PIXMA TS8240a	PIXMA TS705a	PIXMA TS5352a	PIXMA TS3355
PIXMA TS8250a	PIXMA TS7440	PIXMA TS5353	PIXMA TS3440
PIXMA TS8251	PIXMA TS7440a	PIXMA TS5353a	PIXMA TS3450
PIXMA TS8252	PIXMA TS7450	PIXMA TS5355	PIXMA TS3451
PIXMA TS8340	PIXMA TS7450a	PIXMA TS5355a	PIXMA TS3452
PIXMA TS8340a	PIXMA TS7450i	PIXMA TS6040	PIXMA TS3550i
PIXMA TS8350	PIXMA TS7451	PIXMA TS6050	PIXMA TS3551i
PIXMA TS8350a	PIXMA TS7451a	PIXMA TS6051	PIXMA TS5040
PIXMA TS8351	PIXMA TS7451i	PIXMA TS6052	PIXMA TS5050
PIXMA TS8351a	PIXMA TS7640	PIXMA TS6140	PIXMA TS5051
PIXMA TS8352	PIXMA TS7640i	PIXMA TS6150	PIXMA TS5053
PIXMA TS8352a	PIXMA TS7650i	PIXMA TS6151	PIXMA TS5055
PIXMA TS8740	PIXMA TS7740i	PIXMA TS6240	PIXMA TS5140
PIXMA TS8750	PIXMA TS7750i	PIXMA TS6250	PIXMA TS5150
PIXMA TS9040	PIXMA TS8040	PIXMA TS6251	PIXMA TS5151
PIXMA TS9050	PIXMA TS8050	PIXMA TS6340	PIXMA TS5340
PIXMA TS9055	PIXMA TS8051	PIXMA TS6340a	PIXMA TS5340a
PIXMA TS9140	PIXMA TS8052	PIXMA TS6350	PIXMA TS5350
PIXMA TS9150	PIXMA TS8053	PIXMA TS6350a	PIXMA TS5350a
PIXMA TS9155	PIXMA TS8140	PIXMA TS6351	PIXMA TS5350i
PIXMA TS9540	PIXMA TS8150	PIXMA TS6351a	PIXMA TS5351i
PIXMA TS9541C	PIXMA TS8151	PIXMA TS704	PIXMA TS5351
PIXMA TS9550	PIXMA TS8152	PIXMA TS704a	PIXMA TS5351a
PIXMA TS9551C	PIXMA TS8240	PIXMA TS705	PIXMA TS5352



מדפסות תואמות

MAXIFY סדרה

MAXIFY MB5140	MAXIFY GX7040	MAXIFY GX5050	MAXIFY BX110 עם סוללה
MAXIFY MB5150	MAXIFY GX7050	MAXIFY GX5140	MAXIFY GX1040
MAXIFY MB5155	MAXIFY GX7140	MAXIFY GX5150	MAXIFY GX1050
MAXIFY MB5440	MAXIFY GX7150	MAXIFY GX5540	MAXIFY GX2040
MAXIFY MB5450	MAXIFY MB2140	MAXIFY GX5550	MAXIFY GX2050
MAXIFY MB5455	MAXIFY MB2150	MAXIFY GX6040	MAXIFY GX3040
MAXIFY iB4140	MAXIFY MB2155	MAXIFY GX6050	MAXIFY GX3050
MAXIFY iB4150	MAXIFY MB2740	MAXIFY GX6140	MAXIFY GX4040
MAXIFY GX5040	MAXIFY MB2750	MAXIFY GX6150	MAXIFY GX4050
MAXIFY GX5050	MAXIFY MB2755	MAXIFY GX6550	MAXIFY GX5040

imagePRESS סדרה

*imagePRESS V800	*imagePRESS C810	imagePRESS C265	*imagePRESS C10000VP
*imagePRESS V900	*imagePRESS C9010V	imagePRESS C270	*imagePRESS C10010VP
*imagePRESS V1000	*imagePRESS C910	*imagePRESS C710	imagePRESS C165
*imagePRESS V1350	*imagePRESS V700	*imagePRESS C8000VP	imagePRESS C170

imageFORCE

imageFORCE C7165	imageFORCE C5170	imageFORCE C5160	imageFORCE C5140
			imageFORCE C5150

גילוי נאות
PRISMAsync אינו נתמך



מדפסות תואמות

סדרה imageRUNNER ADVANCE

imageRUNNER ADVANCE DX C5740i	imageRUNNER ADVANCE DX C3935i	imageRUNNER ADVANCE C3525i	imageRUNNER ADVANCE C256i
imageRUNNER ADVANCE DX C5750i	imageRUNNER ADVANCE DX C259i	imageRUNNER ADVANCE C3530i	imageRUNNER ADVANCE C356i
imageRUNNER ADVANCE DX C5760i	imageRUNNER ADVANCE DX C359i	imageRUNNER ADVANCE 3530i ES	imageRUNNER ADVANCE C356P
imageRUNNER ADVANCE DX C5840i	imageRUNNER ADVANCE DX C359P	imageRUNNER ADVANCE DX C3720i	imageRUNNER ADVANCE DX C257i
imageRUNNER ADVANCE DX C5850i	imageRUNNER ADVANCE C5535i	imageRUNNER ADVANCE DX C3725i	imageRUNNER ADVANCE DX C357i
imageRUNNER ADVANCE DX C5860i	imageRUNNER ADVANCE C5540i	imageRUNNER ADVANCE DX C3730i	imageRUNNER ADVANCE DX C357P
imageRUNNER ADVANCE DX C5870i	imageRUNNER ADVANCE C5540i ES+ II	imageRUNNER ADVANCE DX C3822i	imageRUNNER ADVANCE C475i
imageRUNNER ADVANCE C7565i	imageRUNNER ADVANCE C5550i	imageRUNNER ADVANCE DX C3826i	imageRUNNER ADVANCE C475iZ
imageRUNNER ADVANCE C7570i	imageRUNNER ADVANCE C5560i	imageRUNNER ADVANCE DX C3830i	imageRUNNER ADVANCE DX C477i MFP
imageRUNNER ADVANCE C7580i	imageRUNNER ADVANCE C5560i ES	imageRUNNER ADVANCE DX C3835i	imageRUNNER ADVANCE DX C477iZ MFP
imageRUNNER ADVANCE DX C7765i	imageRUNNER ADVANCE C5560i ES+	imageRUNNER ADVANCE DX C3922i	imageRUNNER ADVANCE DX C478i
imageRUNNER ADVANCE DX C7770i	imageRUNNER ADVANCE C5560i ES+ II	imageRUNNER ADVANCE DX C3926i	imageRUNNER ADVANCE DX C478iZ
imageRUNNER ADVANCE DX C7780i	imageRUNNER ADVANCE DX C5735i	imageRUNNER ADVANCE DX C3930i	imageRUNNER ADVANCE C3520i

סדרה imageRUNNER

imageRUNNER C3326i	imageRUNNER C3226i	imageRUNNER C1533iF	imageRUNNER C1538iF
--------------------	--------------------	---------------------	---------------------

סדרה i-SENSYS X ו-i-SENSYS

i-SENSYS X C1538iF II	i-SENSYS X C1127P	סדרת i-SENSYS MF740	i-SENSYS LBP722Cdw
i-SENSYS X C1538P II	סדרת i-SENSYS X C1333i	סדרת i-SENSYS MF750	i-SENSYS LBP732Cdw
i-SENSYS X C1936P	i-SENSYS X C1333P	סדרת i-SENSYS MF640	i-SENSYS LBP852Cx
i-SENSYS X C1946P	i-SENSYS X C1533iF II	סדרת i-SENSYS MF650	סדרת i-SENSYS LBP620
	i-SENSYS X C1533P	i-SENSYS MF832Cdw	סדרת i-SENSYS LBP630
	i-SENSYS X C1533P II	i-SENSYS MF842Cdw	סדרת i-SENSYS LBP660
	i-SENSYS X C1538P	סדרת i-SENSYS X C1127i	סדרת i-SENSYS LBP670