ZGODNE DRUKARKI

imagePROGRAF Series

imagePROGRAF GP-200	imagePROGRAF TX-4000	imagePROGRAF iPF710	imagePROGRAF iPF840
imagePROGRAF GP-2000	imagePROGRAF TX-4000 MFP T36	imagePROGRAF iPF720	imagePROGRAF iPF840 MFP M40
imagePROGRAF GP-300	imagePROGRAF TX-4100	imagePROGRAF iPF750	imagePROGRAF iPF8400
imagePROGRAF GP-4000	imagePROGRAF TX-4100 MFP Z36	imagePROGRAF iPF750 M40 MFP	imagePROGRAF iPF8400S
imagePROGRAF PRO-2000	imagePROGRAF TZ-30000	imagePROGRAF iPF755	imagePROGRAF iPF8400SE
imagePROGRAF PRO-2100	imagePROGRAF TZ-30000 MFP Z36	imagePROGRAF iPF755 M40 MFP	imagePROGRAF iPF850
imagePROGRAF PRO-4000	imagePROGRAF iPF500	imagePROGRAF iPF760	imagePROGRAF iPF850 MFP M40
imagePROGRAF PRO-4000S	imagePROGRAF iPF5000	imagePROGRAF iPF760 M40 MFP	imagePROGRAF iPF9000
imagePROGRAF PRO-4100	imagePROGRAF iPF510	imagePROGRAF iPF765	imagePROGRAF iPF9000S
imagePROGRAF PRO-4100S	imagePROGRAF iPF5100	imagePROGRAF iPF765 M40 MFP	imagePROGRAF iPF9100
imagePROGRAF PRO-6000	imagePROGRAF iPF600	imagePROGRAF iPF770	imagePROGRAF iPF9400
imagePROGRAF PRO-6000S	imagePROGRAF iPF6000S	imagePROGRAF iPF770 MFP L36	imagePROGRAF iPF9400S
imagePROGRAF PRO-6100	imagePROGRAF iPF605	imagePROGRAF iPF770 MFP L36e	imagePROGRAF PRO-1000
imagePROGRAF PRO-6100S	imagePROGRAF iPF610	imagePROGRAF iPF770 MFP M40	imagePROGRAF PRO-300
imagePROGRAF TA-20	imagePROGRAF iPF6100	imagePROGRAF iPF780	
imagePROGRAF TA-30	imagePROGRAF iPF6200	imagePROGRAF iPF780 MFP M40	
imagePROGRAF TM-200	imagePROGRAF iPF6300	imagePROGRAF iPF785	
imagePROGRAF TM-200 MFP L24ei	imagePROGRAF iPF6300S	imagePROGRAF iPF785 MFP M40	
imagePROGRAF TM-205	imagePROGRAF iPF6350	imagePROGRAF iPF8000	
imagePROGRAF TM-300	imagePROGRAF iPF6400	imagePROGRAF iPF8000S	
imagePROGRAF TM-300 MFP L36ei	imagePROGRAF iPF6400S	imagePROGRAF iPF810	
imagePROGRAF TM-300 MFP Z36	imagePROGRAF iPF6400SE	imagePROGRAF iPF8100	
imagePROGRAF TM-305	imagePROGRAF iPF6450	imagePROGRAF iPF815	
imagePROGRAF TM-305 MFP T36	imagePROGRAF iPF650	imagePROGRAF iPF815 M40 MFP	
imagePROGRAF TM-305 MFP Z36	imagePROGRAF iPF655	imagePROGRAF iPF820	
imagePROGRAF TX-2000	imagePROGRAF iPF670	imagePROGRAF iPF825	
imagePROGRAF TX-2100	imagePROGRAF iPF670 MFP L24	imagePROGRAF iPF825 M40 MFP	
imagePROGRAF TX-3000	imagePROGRAF iPF670 MFP L24e	imagePROGRAF iPF830	
imagePROGRAF TX-3000 MFP T36	imagePROGRAF iPF680	imagePROGRAF iPF830 MFP M40	
imagePROGRAF TX-3100	imagePROGRAF iPF685	imagePROGRAF iPF8300	
imagePROGRAF TX-3100 MFP Z36	imagePROGRAF iPF700	imagePROGRAF iPF8300S	

Canon

ZGODNE DRUKARKI

PIXMA Series

PIXMA E204	PIXMA G3460	PIXMA MG3650	PIXMA TS3140
PIXMA E304	PIXMA G3500	PIXMA MG5740	PIXMA TS3150
PIXMA E3140	PIXMA G3501	PIXMA MG5750	PIXMA TS3151
PIXMA E3340	PIXMA G3510	PIXMA MG5751	PIXMA TS3340
PIXMA E3440	PIXMA G3520	PIXMA MG5752	PIXMA TS3350
PIXMA E414	PIXMA G3560	PIXMA MG5753	PIXMA TS3351
PIXMA E4240	PIXMA G4400	PIXMA MG6840	PIXMA TS3352
PIXMA E474	PIXMA G4410	PIXMA MG6850	PIXMA TS3355
PIXMA G1400	PIXMA G4411	PIXMA MG6851	PIXMA TS3440
PIXMA G1410	PIXMA G4500	PIXMA MG6852	PIXMA TS3450
PIXMA G1411	PIXMA G4510	PIXMA MG6853	PIXMA TS3451
PIXMA G1420	PIXMA G4511	PIXMA MG7740	PIXMA TS3452
PIXMA G1500	PIXMA G5040	PIXMA MG7750	PIXMA TS5040
PIXMA G1501	PIXMA G5050	PIXMA MG7751	PIXMA TS5050
PIXMA G1510	PIXMA G540	PIXMA MG7752	PIXMA TS5051
PIXMA G1520	PIXMA G550	PIXMA MG7753	PIXMA TS5053
PIXMA G2400	PIXMA G6040	PIXMA PRO-200	PIXMA TS5055
PIXMA G2410	PIXMA G6050	PIXMA TR150	PIXMA TS5140
PIXMA G2411	PIXMA G640	PIXMA TR4540	PIXMA TS5150
PIXMA G2415	PIXMA G650	PIXMA TR4550	PIXMA TS5151
PIXMA G2420	PIXMA G7040	PIXMA TR4551	PIXMA TS5340
PIXMA G2460	PIXMA G7050	PIXMA TR4640	PIXMA TS5350
PIXMA G2500	PIXMA GM2050	PIXMA TR4650	PIXMA TS5351
PIXMA G2501	PIXMA GM4040	PIXMA TR7540	PIXMA TS5352
PIXMA G2510	PIXMA GM4050	PIXMA TR7550	PIXMA TS5353
PIXMA G2520	PIXMA MG3040	PIXMA TR8540	PIXMA TS5355
PIXMA G2560	PIXMA MG3050	PIXMA TR8550	PIXMA TS6040
PIXMA G3400	PIXMA MG3051	PIXMA TS204	PIXMA TS6050
PIXMA G3410	PIXMA MG3052	PIXMA TS205	PIXMA TS6051
PIXMA G3415	PIXMA MG3053	PIXMA TS304	PIXMA TS6052
PIXMA G3420	PIXMA MG3640	PIXMA TS305	PIXMA TS6140

Canon

ZGODNE DRUKARKI

PIXMA Series

PIXMA TS6150	PIXMA TS7440	PIXMA TS8151	PIXMA TS9040
PIXMA TS6151	PIXMA TS7450	PIXMA TS8152	PIXMA TS9050
PIXMA TS6240	PIXMA TS7451	PIXMA TS8240	PIXMA TS9055
PIXMA TS6250	PIXMA TS8040	PIXMA TS8250	PIXMA TS9140
PIXMA TS6251	PIXMA TS8050	PIXMA TS8251	PIXMA TS9150
PIXMA TS6340	PIXMA TS8051	PIXMA TS8252	PIXMA TS9155
PIXMA TS6350	PIXMA TS8052	PIXMA TS8340	PIXMA TS9540
PIXMA TS6351	PIXMA TS8053	PIXMA TS8350	PIXMA TS9541C
PIXMA TS704	PIXMA TS8140	PIXMA TS8351	PIXMA TS9550
PIXMA TS705	PIXMA TS8150	PIXMA TS8352	PIXMA TS9551C

MAXIFY Series

MAXIFY GX6040	MAXIFY MB2150	MAXIFY MB5140	MAXIFY MB5455
MAXIFY GX6050	MAXIFY MB2155	MAXIFY MB5150	MAXIFY iB4140
MAXIFY GX7040	MAXIFY MB2740	MAXIFY MB5155	MAXIFY iB4150
MAXIFY GX7050	MAXIFY MB2750	MAXIFY MB5440	MAXIFY GX5040
MAXIFY MB2140	MAXIFY MB2755	MAXIFY MB5450	MAXIFY GX5050

Canon

ZGODNE DRUKARKI

imagePRESS Series

imagePRESS C10000VP*	imagePRESS C170	imagePRESS C810*
imagePRESS C10010VP*	imagePRESS C710*	imagePRESS C9010VP
imagePRESS C165	imagePRESS C8000VP*	imagePRESS C910*

imageRUNNER ADVANCE Series

imageRUNNER ADVANCE C256i	imageRUNNER ADVANCE DX C478iZ	imageRUNNER ADVANCE C5535i	imageRUNNER ADVANCE DX C5870i
imageRUNNER ADVANCE C356i	imageRUNNER ADVANCE C3520i	imageRUNNER ADVANCE C5540i	imageRUNNER ADVANCE C7565i
imageRUNNER ADVANCE C356P	imageRUNNER ADVANCE C3525i	imageRUNNER ADVANCE C5550i	imageRUNNER ADVANCE C7570i
imageRUNNER ADVANCE DX C257i	imageRUNNER ADVANCE C3530i	imageRUNNER ADVANCE C5560i	imageRUNNER ADVANCE C7580i
imageRUNNER ADVANCE DX C357i	imageRUNNER ADVANCE DX C3720i	imageRUNNER ADVANCE DX C5735i	imageRUNNER ADVANCE DX C7765i
imageRUNNER ADVANCE DX C357P	imageRUNNER ADVANCE DX C3725i	imageRUNNER ADVANCE DX C5740i	imageRUNNER ADVANCE DX C7770i
imageRUNNER ADVANCE C475i	imageRUNNER ADVANCE DX C3730i	imageRUNNER ADVANCE DX C5750i	imageRUNNER ADVANCE DX C7780i
imageRUNNER ADVANCE C475iZ	imageRUNNER ADVANCE DX C3822i	imageRUNNER ADVANCE DX C5760i	imageRUNNER ADVANCE DX 6860i
imageRUNNER ADVANCE DX C477i MFP	imageRUNNER ADVANCE DX C3826i	imageRUNNER ADVANCE DX C5840i	imageRUNNER ADVANCE DX 6870i
imageRUNNER ADVANCE DX C477iZ MFP	imageRUNNER ADVANCE DX C3830i	imageRUNNER ADVANCE DX C5850i	
imageRUNNER ADVANCE DX C478i	imageRUNNER ADVANCE DX C3835i	imageRUNNER ADVANCE DX C5860i	

imageRUNNER Series

imageRUNNER C1538iF	imageRUNNER C1533iF	imageRUNNER C3226i

i-SENSYS/i-SENSYS X Series

i-SENSYS X C1538P	i-SENSYS X C1533P	i-SENSYS LBP620 series	i-SENSYS X C1127i series
i-SENSYS MF832Cdw	i-SENSYS LBP852Cx	i-SENSYS MF740 series	i-SENSYS X C1127P
i-SENSYS LBP722Cdw	i-SENSYS LBP660 series	i-SENSYS MF640 series	

Wykluczenie odpowiedzialności

*Technologia PRISMAsync nie jest obsługiwana

Canon